Remote control functions in Squeezeslave mode



| | Hauppauge | SageTV | Front Panel | Logitech |
|-----------|--------------|--------------|--------------|--------------|
| MediaMVP | \checkmark | \checkmark | | |
| STX-HD100 | \checkmark | \checkmark | \checkmark | \checkmark |
| STP-HD200 | \checkmark | \checkmark | | \checkmark |
| STP-HD300 | \checkmark | \checkmark | | \checkmark |



ħ m 44 н . ◄) ((۲ 3 6 WXY 9 8 E 0 0 J Q V Logitech

- Power on SageTV / WOL
- SageTV Home Menu / WOL
- O Load Playlist 1..9 (playlists named 1 to 9 must exist already)
- Load Playlist 0 (all music library)
- Volume Up / Down / Mute
- Begin / Previous
- Skip Backward (each press 10 seconds)
- Next
- Skip Forward (each press 10 seconds)
- Play / Stop (excluding STX-HD100 Front Panel)
- Pause
- Shuffle (cycle through options like squeezebox remote)
- Repeat (cycle through options like squeezebox remote)
- O Sleep / WOL (cycle through options like squeezebox remote)

STX-HD100 Front Panel



